SPZ500 SPARE PARTS

SPARE PARTS NAME	PICTURE
MIXING PLATE MIDDLE	
MIXING PLATE (Gear Box Side)	
MIXING PLATE RIGHT, REAR END	(00
MIXING PLATE HOLDER MIDDLE	
MIXING PLATE HOLDER REAR / FRONT (with Angle)	
GEAR BOX SHAFT	
SQUARE HOLDER	300000
WEAR PLATE, THICKNESS 6MM	
WEAR PLATE WITH OUTLET, THICKNESS 6MM	0/0/0
RUBBER DISC (Ø180 x Ø62 x Ø8)	
WEAR SLEEVE (Ø70 x Ø60 x Ø125)	
PERROT COUPLING (Suitable for Poly Pipe ØOD90mm, ID 76mm)	
3M FLEXIBLE HOSE WITH FEMALE, 3 PERROT COUPLING (Hose: OD 85mm, ID 64mm, 5 Meter) 5M FLEXIBLE HOSE WITH FEMALE, 3 PERROT	
COUPLING	
OUTLET PIPE	

SPZ500 SPARE PARTS

NYLON COUPLING SET	The state of the s
PRESSURE GAUGE	
TOP COVER O-RING	
INSPECTION HOLE O-RING	
PINION GEAR	
PINION GEAR	
GEAR 61T	
GEAR 72T	
GEAR BOX	
MOTOR	
SWITCH BOX	

SPZ500 SPARE PARTS

COMPRESSOR HOSE 2 METER C/W CLAMP	
CUP SEAL	
BEARING SHAFT C/W BUSH	